

# Brook Engineering Pty Ltd

ABN 77 052 138 164

**Our Contact** John Brook  
E-mail john@brookeng.com.au

13 Pleasant Grove  
Holden Hill SA 5088  
HOLDEN HILL SA 5088  
Telephone : +61 8 8264 3895  
Facsimile : +61 8 8396 4788

## Olive Oil Sampling System

### Set up requirements

1. Standard 240V 10Amp single phase supply (3 pin plug)
  2. 10 litres of water for the heated malaxer bath (hand filled)
  3. A bench space of 800mm x 2000mm x 500-800mm high
  4. A bin for the spent pulp
  5. A container, detergent and sponge for washing components after each run
  6. Scales to weigh the olives (800grams per load max.) and the oil
  7. The approximate weights of the system components are:  
Hammer Mill, 55Kg  
Malaxer, 40Kg (without water)  
Centrifuge, 50Kg  
Control Box, 15Kg
- The heaviest three units need two people per unit to carry them comfortably.